



User Manual of HTVRONT
Automatic Heat Press 2 - Smart


Included in the Box

EN

Thank you for purchasing HTVRONT Automatic Heat Press 2 - Smart. Before using this product for the first time, please read this user manual carefully and keep it properly for future reference.

- | | |
|--|---------------------------|
| • HTVRONT Automatic Heat Press 2 - Smart × 1 | • Teflon Sheet × 1 |
| • Heat Press Mat × 1 | • User Guide Envelope × 1 |

Device Overview



- | | | | |
|------------------|------------|-------------------|---------------|
| 1. Touch Screen | 2. Buttons | 3. Indicator Ring | 4. Heat Plate |
| 5. Ironing Board | 6. Base | | |

Details of Buttons

Functions



Power

- After powering on, the "Power" button flashes white. Press the "Power" button once to turn on the device, and the touch screen will flip and ascend. The "Power" button lights white after turning on;
- Press the "Power" button again to turn off the device, and the touch screen will descend to its original position.



Home

Press the "Home" button once to return to the "Home" page and stop the ongoing ironing task.



Start

Press the "Start" button once to iron automatically with a countdown. The "Start" button flashes red when preheating, then turns green once it reaches the set temperature.

Details of Indicator Ring

Color	Status
Green	• The device is powered on; • The device has reached the set temperature.
Red	The device is preheating.



Memory mode

The selected material and substrate will be remembered for the next operation.



Emergency stop

Press any physical buttons or tap "Stop" on the screen to stop ironing, and the heat plate will stop descending and back to the original position.



Back to the default setting (100°C/ 210°F, 20 s, 20 kg/50 lb)

Press the "Power" button for 5 s to turn off the device and reset the settings.



Remote APP control

Connect the phone to the device via BLUETOOTH® and operate it through the mobile app.



Auto turn-off

This device will turn off automatically if there's no operation in 15 minutes. There will be beeps, and the "Power" button flashes white in the last 10 seconds before the shutdown.



Auto ironing

After setting, tap "Auto" on the screen to start automatic ironing. Once the ironing board is pushed back into place, the device will press down on the project continuously without tapping "Start." Tap "Auto" again to exit.



Firmware update

Turn on the "Network" to update the firmware.







Details of Indicator Light

Usage Notes

Buttons	Color	Status
Power	Flash White	• The device is standing by; • The device is about to turn off.
Power & Home	Flash White	• The device is connecting via BLUETOOTH®.
Start	Green	• The device has reached the set temperature.
	Flash Red	• The heat plate is descending when not reaching the set temperature; • The device is malfunctioning.
	Red	• The heat plate has not reached the set temperature; • The device is ready to heat up.
	Flash Green	• The heat plate is descending.

1. Do NOT move or stop the touch screen manually. Otherwise, the screen may malfunction or cause injuries;
2. Please ensure it's clear around the touch screen to avoid damage;
3. Please ensure the ironing board has been fully pushed back before starting ironing;
4. Under the Auto mode, the heat plate will press down automatically once the ironing board is pushed back inside. Note to release the handle in time to avoid scald.

Instructions for Use



Touch Screen System

Language	Tap "System" - "Language" to switch among six languages: English, German, French, Spanish, Italian, and Korean.
Units	Tap "System" - "Units" to convert temp (°C/°F) or pressure units(kg/lb).
Screen Adjustment	Tap "System," - "Screen Angle," - "Ascend," or "Descend" to adjust the screen angle until you stop tapping.
Screen Sound	Tap "System" - "Screen Sound" to turn on/off the sound prompts.
Network Settings	Tap "System" - "Network" to connect your network. This setting only applies to firmware updating.
Firmware Updates	Tap "System" - "Firmware Updates" to update your firmware (*Please ensure the device is connected via network).
BLUETOOTH®	Tap "System" - "BLUETOOTH®" to connect the device via BLUETOOTH®. This setting only applies to device connection.

Precautions

To reduce the risk of electric shock, this product has a polarized plug (one blade is wider than the other). This plug is intended to fit in a polarized outlet only one way. When the plug does not fit fully in the outlet, reverse the plug. When it still does not fit, contact a qualified electrician to install the proper outlet. Do not change the plug in any way. Close supervision is required when this product is used near children.

HOUSEHOLD USE ONLY.

DO NOT IMMERSE IN WATER.

When the appliance provided with a power-supply cord that is less than 4 - 1/2 feet (1.4 m) long shall be provided with instructions that include the following information:

- A short power-supply cord (or short detachable power-supply cord) is provided to reduce the risks resulting from becoming entangled in or tripping over a longer cord;
- Extension cords (or longer detachable power-supply cords) are available and are not prohibited from being used when care is exercised in their use.
- When an extension cord is used:
 - The marked electrical rating of the detachable power-supply cord or extension cord shall be no less than the marked electrical rating of the product;
 - The longer cord shall be arranged so that it does not drape over the counter-top or tabletop where it is capable of being tripped over, snagged, or pulled on unintentionally, especially by children.

1. Do NOT use this product outdoors. It's ONLY for household use;
2. You can ONLY use this product on a flat, stable, and heat-resistant surface;
3. Keep the product away from flammables while in use;
4. When using this product, please keep an eye on it to avoid accidents. Turn off the product and unplug the power cord while leaving;
5. Do NOT touch the heat plate after powering on to prevent burns;
6. Do NOT let the power cord touch the heat plate during the operation;
7. Please note the distance between your hands and the heat plate while pushing back the ironing board to prevent burns;
8. After use, please wait until the device is completely cool before storing it away;
9. Please unplug the power cord after use or before cleaning the product to avoid electric leaks and any risks;
10. Do NOT immerse the product in any liquid;
11. When there are beeps and "E1/E2/E3/E4/E5" on the screen, please cut the power immediately and restart. Feel free to contact HTVRONT's customer service if you have more questions;
12. If the product is malfunctioning or damaged, please stop using the product immediately and contact LOKLiK's customer service;
13. Children under 14 MUST have adult supervision while using the device.

CLEANING AND MAINTENANCE

Before performing cleaning and maintenance, ensure that the power supply has been turned off, unplug the power cord, and wait for the body to completely cool before performing cleaning and maintenance.

Do not put the appliance into water. Please use a soft dry cloth to dry the body without using special cleaning agents to clean it.

When the product is not in use, please clean it and place it in a clean and ventilated place, and store it out of the reach of children.

Specifications

HTVRONT Automatic Heat Press 2 - Smart

Model	HPA01-2	Pressure	20 - 80 kg (50 - 170 lb)
Input	220 - 240V~ 50 - 60Hz 1400 - 1600W 120V~ 60Hz 1500W; 100V~ 60Hz 1200W 110V~ 60Hz 1260W; 220V~ 50Hz 1370W	Heat Plate Size	38.1 x 38.1 cm/15 x 15 in
Temperature	100 - 210°C (210 - 410°F)	Time	1 - 999 s
Product Dimensions	54.0 x 44.5 x 33.0 cm/ 21.3 x 17.5 x 12.9 in	Package Dimension	58.5 x 48.5 x 38.0 cm/ 23.0 x 19.1 x 15.0 in
Product Weight	20.0 kg/44.1 lb	Package Weight	22.5 kg/49.6 lb

Q1: What to do if I cannot find my materials or substrates in the "Material Library"?

- A1: Try with similar materials or substrates in the "Material Library";
A2: Customize proper ironing parameters for your materials or substrates as needed.

Q2: Why have my customized settings been cleared?

- A1: The customized settings will be cleared after restoring the device back to the default setting.

Q3: Why does the device emit slight smoke?

- A1: It's normal as the moisture caused by a long-time unused or a humid environment will evaporate when heated;
A2: It is normal as the sublimation ink will sublimate into gas at high temperatures when using sublimation materials.

Q4: How to get a successful heat transfer result?

- A1: Make sure you have followed the instructions correctly;
A2: Make sure you have selected the correct materials and substrates;
A3: For fabrics, please iron them first to remove wrinkles before heat transferring;
A4: It is recommended to use HTVRONT's materials for the best ironing results.

Q5: Why is my device making beep sounds?

- A1: Beep once: the device is powered, turned on/off, finishes time/temp/pressure setting, or the countdown ends;
A2: Beep constantly: the heat plate is pressing down;
A3: Beep constantly with "E1/2/3/4/5" on the screen: cut the power immediately and restart the device. Contact HTVRONT's customer service if this step doesn't work.

Q6: What to do if the screen cannot descend/ascend accordingly?

- A1: Cut off the power, re-power the device, and restart the device;
A2: Do NOT move the touch screen manually. Otherwise, the screen may malfunction;
A3: Contact HTVRONT's customer service if the above steps don't work.

Q7: Why cannot I update my firmware via a network connection?

- A1: Please check your network signal and update your firmware under a good network connection (Required internet speed: > 8.5 MB/s).

Q8: What to do if fail to connect the device via BLUETOOTH®?

- A1: Ensure the device is powered on;
A2: Ensure the computer/phone's BLUETOOTH® is turned on;
A3: Ensure the device is within 5 meters around the computer/phone.

A9: Where do I find the device's S/N code?

- A1: You can find the S/N code on the right side of the device's base;
A2: You can find the S/N code on the device's package box.

Q10: How to update firmware?

- A1: Connect the device via the network and follow the instructions on the pop-up window to update;
A2: Ensure the device is powered on.

Q11: How to check my firmware version info?

- A1: Connect the phone to the device via BLUETOOTH®; find the "Firmware Update" in the HTVRONT app and check the version info.

HTVRONT Automatic Heat Press 2 - Smart Limited Warranty

This product is covered by a one-year warranty from the date of purchase. If a defect occurs under normal use within the warranty period, we will provide warranty service. Proof of purchase is required to claim warranty service. HTVRONT accessories are covered by a free warranty for three months from the date of purchase. In the event that any warranty terms conflict with applicable local laws and regulations, the local laws will take precedence.

To the extent permitted by applicable laws, HTVRONT is not responsible for the warranty in the following situations: malfunctions caused by improper use, maintenance, and storage by consumers; malfunctions caused by self-repair or dismantling by those who do not undertake the three-guarantee repair without the permission of our company; products that can continue to be used after repair when the warranty expired; damage caused by force majeure. Meanwhile, HTVRONT disclaims all implied and legal warranties, including warranties of merchantability and fitness for a particular purpose. The warranties that are allowed to be denied are for the duration of this warranty.

Proof of purchase may be required to verify warranty eligibility.

Scan the QR code below to
download the HTVRONT app (*for phone and iPad):



Android



iOS